Activity Recognition System


Rok Cej


Overview

- 3 types of activities: None, Walking, Jumping
- Accelerometer and gyroscope
- Complementary filter, standard deviation
- HTTP server to display results

Calibration

- 3 seconds (300 samples)
- Board must be completely still and horizontally aligned
- Ready when LEDs stop blinking








Main loop

- 1. Read accelerometer and gyroscope data
- 2. Apply complementary filter → roll and pitch
 - Low-pass filter on accelerometer data
 - High-pass filter on gyroscope data

- 3. Extract vertical and horizontal components of acceleration
- 4. Compute standard deviation
- 5. Detect activity



Server

- / Home page
- /script.js Frontend JavaScript code
- /data
 Orientation data
- /history Acceleration data

▼ rot:
 0: 0.17
 1: -0.36

activity:	0
▶ acc:	[]
▶ dev:	[]
current_step:	8856


Welcome to ESP8266

Uptime: 00:08:37


User agent: Mozilla/5.0 (Windows NT 10.0; Win64; x64; rv:89.0) Gecko/20100101 Firefox/89.0

Frontend

• WebGL - Visualize board orientation



• Chart.js - Plot acceleration data graph



Activity: None

Activity: Walking

Activity: Jumping

Demonstration

http://192.168.100.33/